

WARNING!!!

Please read through all instructions before proceeding with installation.

BEFORE INSTALLING CABINET:

- 1. Renters should consult with their landlord before proceeding.**
- 2. Be aware of any electrical pipes, plumbing or vents that may be enclosed behind the chosen wall for mounting. Do not drill, pierce, or hammer into any of these objects.**
- 3. Installation in areas where seismic events can occur may require additional support to prevent side-to-side movement.**
- 4. These instructions are recommendations in nature and are not intended to supersede any local or state building codes.**
- 5. The back panel of the cabinet is not sufficient in strength to support the cabinet itself. Any anchoring method must include fasteners through the back panel and into the center shelf, and/or outside frame.**
- 6. These instructions are for sheetrock installations only, for any other type of wall (i.e., brick, mortar, tile, etc.), please consult local codes and a professional, if not familiar with such installations.**
- 7. Make sure Z Clips are attached to a stud behind the drywall.**

View the YouTube clip for proper use of Eagle Z Clips:

<https://video.search.yahoo.com/yhs/search?fr=yhs-mozilla-001&hsimp=yhs-001&hspart=mozilla&p=Z-clip+wall+installation#id=6&vid=912261cf7271d75455bd0a5a122a716a&action=view>

INSTALLATION INSTRUCTIONS

Tools needed: pencil, level, power drill, drill bit set, #2 Phillips head bit for power drill, #2 Phillips head screwdriver, hammer, tape measure, ladder or step stool, plastic mallet

(OVER)

BACO CORP. ASSUMES NO LIABILITY FOR DAMAGES INCURRED DUE TO IMPROPER INSTALLATION, and is limited to repair or replacement of cabinet only and not responsible for any other damage incurred.

- 1. Locate Placement of Cabinet – Once the cabinet is placed where you want, level it with a standard level. Mark the wall with a pencil, locating the left and right sides of the cabinet. Mark the wall with a pencil locating the top of the cabinet.**
- 2. Measure down from the top of the cabinet to the inside top of the Z Clip opening. In the photo, that dimension is approximately 11 5/8". (Z Clips on cabinet have been mounted for you, centered, 6" apart.)**



- 3. Mark the top of the Z Clip opening location on the wall, place first Z Clip in the location you want, and mark the two holes. Repeat process for second clip.**
- 4. If expandable wall anchors are necessary, drill the pilot holes. Install anchors using manufacturers instructions.**
- 5. Install Z-Clips on the wall using either the screws that were furnished with the expandable anchors, or the appropriate sized screw for the project, making sure as you go to mount them levelly.**
- 6. Once Z Clips are mounted on wall, the cabinet is ready to hang.**

NOTE: Using the existing holes for the Z Clips on back of the cabinet, cabinet can be turned in the opposite direction as to allow hanging with doors on top.